

## Configuring the Serial Ports under Windows CE for the Vortex86-6082

- 1.) Go to Start -> Settings -> Network and Dial-Up Connections
- 2.) Go to File -> "New"
- 3.) In the text box within the 'Make New Connection' dialog box that pops up, enter 'COM1'
- 4.) Select 'Direct Connection'
- 5.) Click 'Next'
- 6.) In the drop-down 'Select a device:' box, select 'Serial Cable on COM1:'.
- 7.) Click 'Finish'
- 8.) An icon, labeled 'COM1' is now in the folder
- 9.) Repeat the same steps above for 'COM2'
- 10.) When completed COM1 and COM2 configuration, click the 'Start' button in the lower left of the screen, then hit 'Suspend'. The screen will go blank, because it's saving the configurations you just made.
- 11.) Press a key, and the screen will come back
- 12.) Your COM ports are now configured